

SKY CLIMBER®

PARTS LIST

GEAR BOX ATTACHMENT MODEL G4

NOTE: No parts can be shipped without model and serial numbers. Example: Model No. — G4 Serial No. — G1145

Item No.	Part No.	Description	Quantity
1	103-160-2	Screw	1
2	103-159-2	Spacer	1
3	103-254	Wedge Brake Assembly	1
4	103-185	Roll Pin	1
5	103-189	Shoe	1
6	102-149	Lever	1
7	103-41	Nut-Lock	1
8	103-84	Screw	3
9	103-57-3	Bracket	1
10	103-211-1	Seal	1
11	103-209	Retainer	1
12	103-68	Worm Shaft Assembly	1
13	103-21-2	Shaft-Worm	1
14	103-28	Bearing	1
15	103-29	Ring-Retaining	1
16	103-36	Key	1
17	103-30	Worm	1
18	103-31	Spacer	1
19	103-32	Bearing	1
20	103-33	Nut	1
21	103-12-1	Screw	4
22	103-143	Washer	4
23	103-237	Clip	1
24	103-11-1	Cover	1
25	103-150-1	Gasket	1
26	103-25	Shim	A/R
27	103-2	Gear Shaft Assembly	1
28	103-5	Bearing	1
29	103-7	Gear	1
30	103-8	Setscrew	1
31	103-4	Key	1
32	103-3	Shaft	1
33	103-6	Bearing	1
34	103-70-1	Dowel	2
35	103-149	Breather	1
36	103-9	Oil Seal	1
37	103-16	Key	1
38	103-10-1	Driver	1
39	103-162-1	Element-Coupling	1
40	103-146	Setscrew	1
41	103-50-1	Housing-Worm Gear	1
42	103-14	Plug-Pipe	1
43	103-240	Handle Assembly	1
44	103-239	Capscrew	1
45	107-629	Washer-Plain	1
46	103-242-1	Grip	1
47	103-241	Handle	1
48	103-238	Nut-Jam	1

